

Striking Instructions

1. Close all sidewall windows, and zip bed windows up. Note: In Mesa III unit lower kitchen to travel position. Be sure handle is completely down.
2. To remove door - lift unit to disengage hanger brackets - pull forward and place in storage position.
3. Disengage canvas snaps at interior corners and disengage all bed roof and sidewall latches, except for center sidewall latches.
4. Disengage canvas snaps, shock cords under beds, and raise the bed leveling legs to storage position, crank top up off from sidewalls.
5. Disengage corner flap tucked under road cover. Depress sidewall corner and disengage vinyl tent end by sliding it up and out from behind telescope posts. NOTE: Steps 4 and 5 are most efficiently done in sequence at each corner of trailer.
6. Lower bed roof to travel position.
7. Fold sides of canvas onto bed roof then fold over end canvas. Check for clearance of canvas along both edges of bed. Slide beds in at both ends. (On Mesa model disengage the last sidewall latch opposite the door before sliding in front bed.)
8. Disengage center sidewall latches and tilt sidewalls in, raise step door and latch.
9. Crank top firmly down to travel position.
10. Raise body leveling legs.