



(1)



(2)



(3)



(4)

(1) Insert tongue jack wheel in jack sleeve. Remove back locking pin to release jack. (2) Use same locking pin to reset jack in vertical position. Unlock coupler, detach safety chains and electrical hookup. Start leveling trailer by using the tongue jack. Lower front of trailer slightly below level, (3) release rear leveling legs, lock in position and extend them to the ground. Raise front of trailer slightly above level, release front leveling legs, lock in down position and extend them to the ground. Complete leveling of trailer by lowering front with the tongue jack. (4) To adjust a corner further, insert jack handle in notch of that leg and lift in jacking fashion to desired height. To release, lift slightly with handle and depress locking latch (insert) with thumb and jack down. (5) Crank up top. (6) Pull out both beds. (7) Unlatch and open step door. (8) Push the side panels to vertical position and swing down latch on each side of road cover to hold sidewalls in vertical position. (9) Raise bed roofs and pull the tenting down off the bed roofs. (10) Press in on the sidewall corner far enough so that the grey vinyl tent end can be inserted halfway up the telescope post and worked down until it has a snug fit. Insert top of canvas flap underneath the road cover. Fasten snaps at bottom of tenting to trailer sides. (11) Lower bed leg



(5)



(6)



(7)



(8)